



## Kill Paff

**Codice prodotto: 3330052**

**Category: PMC**

Electric diffuser with insecticide and mosquito repellent refill.

### Description:

Electric diffuser with insecticide and mosquito repellent refill based on prallethrin. The dispenser with an on/off button is also suitable for use with insecticide tablets.

### Method of use:

The bottle is fitted with a safety cap. To open, press the cap down and simultaneously unscrew it. After removing the protective cap, screw the bottle into the vaporizer's socket. Do not force the bottle, but screw it firmly.

Plug the vaporizer into a 230 V socket.

The plug can be rotated to fit the socket according to the orientation of the holes.

Ensure that the bottle is always in an upright position.

If you wish to stop the unit, simply unplug it.

If the vaporizer is not used for a long period of time, remove the bottle and screw the protective cap back on.

To replace the bottle, unscrew it firmly in the opposite direction to the initial insertion, in order to overcome the initial resistance.

To clean the vaporizer (once it has been switched off) use a dry cloth or kitchen roll.

Lasts 45 nights if switched on about 6-8 hours per night.

### User:

Professional

### Warnings:

Continuous exposure in the case of sensitive persons (children, asthmatics, etc.) is not recommended.

After application or in case of contact with skin, wash thoroughly with soap and water.

Do not leave the electric diffuser in contact with textiles, paper and combustible materials in general when in operation.

Do not touch the unit while it is operating.

Do not operate the unit in enclosed areas when occupied for a long time.

If the product is used in areas of long-term occupancy or in bedrooms, ventilate the room before returning.

The KILL PAFF refill is only to be used in conjunction with the KILL PAFF electric diffuser. The use of other types of refill in

combination with the KILL PAFF electric diffuser may cause toxicity or flammability risks.



Version: 2026

TDS2

**Kill Paff**

***"Environmental protection"***

**Other (Environmental protection)**

**Notes:**

Medical Device with insecticidal action, use with caution. Always read the label and product information before use.

Attention is drawn to the hazard warnings and symbols on the label.

The text in the specifications corresponds to the label approved by the Ministry of Health.